

# PRODUCT INTRODUCTION





## WARNING

- . KEEP OUT OF REACH OF CHILDREN.
- RISK OF FIRE EXPLOSION.
- DO NOT TAMPER WITH THE BATTERY.

# **USER GUIDELINE**

# GUNN70Ю RX

Reusable Device











# SAFE CHILD LOCK

# INSTRUCTIONS FOR USE

1. Attach the pod to the body kit. Verify the components are securely components are securely engaged. To confirm connection, inhale gently. Activation of the display indicates successful attachment. The device incornorates overcharge protection and an automatic cut-off function.





- 2. BUTTON
  "There are two functions of the button:

  Booster- Press and hold the button while inhaling from the pod to increase output
- flow.

  Child Lock Tap the button three times to activate the Child Lock system. To deactivate, tap three times again."

### SMART SCREEN "The screen displays three attributes of this

- Battery Power The number on the screen
- shows the battery level.

  Child Lock Status A blinking padlock icon indicates that the Child Lock is
- Vape Indicator On the right-hand side of the screen, there are three small arrows that jump to indicate usage."



3. Charge your device when the screen shows 15% battery or less. Please use a certified high-quality adapter and Type-C cable for charging. The screen will display 100% when fully charged.

The circular part is an airflow adjuster. For optimal performance, adjust the airflow to different positions to find the most comfortable airflow setting.

# NOTE



"When traveling by air, remove the pod from the device and store the pod upside down. This reduces the risk of e-liquid leakage caused by changes in cabin air pressure."

